

# Lumo



# Intex Lumo® Corded LED Worklight 6000 Lumens

### **Product Description:**

Designed for cool non-glare illumination and built TradeTuff® for the most demanding work-site conditions. Features advanced Surface-Mount Technology, delivering true representation of colours, optimised colour temperature and even beam patterns, improving lighting effect and efficiency.

# Intex Lumo® Operation:

- 1. To turn on the Worklight press the Power dial (Figure B).
- Adjust the brightness by rotating the stepless Power dial clockwise to increase and anticlockwise to dim [10%-25%-50%-75%-100%].
- 3. To turn off the Worklight press the Power dial.



# SLP6000 Specifications:

 Lumens with Floodlight Attachment
 480-4800

 Socket Output
 8A 1600W

 Lumens (Im)
 600-6000

Watts (W) 60

Voltage (V) AC200-250V/50-60HZ

Colour Temperature (K) 5500-6500
Colour Rendering Index (Ra) CRI>70

Power Cable 3m 3\*1.5sgmm H07RN Cable + 10A Plug

Water Resistance Rating IP54
Impact Resistance Rating IK07
Storage Temperature -20° to 50°
Working Temperature -10° to 40°
Weight (kg) 3.06

Dimensions (mm) 304 x 238 x 102
Warranty 12 Months

AS/NZS 60598.2.5:2015. AS/NZS 61347.1:2016+A1:2018. AS 61347.2.13:2018

#### Contents:

Corded LED Worklight

Instruction Manual

#### Warnings:

- Wear safety goggles whist operating (user and bystanders).
- Avoid looking directly into the beam.
- Do not use the Worklight near open flames.
- Do not cover the lens whilst operating to prevent overheating.
- Do not contaminate the lens with organic solvents.
- Take care to position the Worklight in a careful manner, ensuring the light is properly supported by the stand.
- When using at a height of 3m or greater, take extra precaution to prevent falling objects causing harm to bystanders and or nearby equipment.





intexinternational.com

Lumo® is a registered Trademark of Intex International The information contained in this brochure was correct at the time of printing. E&OE